# Performance Measurement for Sustainable Communities

May 26, 2011

Kevin Ramsey, Ph.D.

U.S. EPA Office of Sustainable Communities

## **Presentation Outline**

- 1. Overview: What is performance measurement?
- 2. A framework for performance measurements
- 3. Example performance measures
- Free online tools for performance measurement and baseline analysis
- 5. Opportunity for technical assistance
- 6. Additional resources



## What is Performance Measurement?

Sustainable community performance measures...

- Systematically compare outcomes over time or space
- Document changes in :
  - the built environment
  - human behavior
  - demographics
  - economic trends
- Measure the effectiveness of policies, programs, or investments at promoting desired outcomes



# Common Goals of Performance Measurement

- Focus attention
- Build consensus
- Promote accountability
- Promote informed decision making





## Uses of performance measures

- Evaluating needs and baseline conditions
- Comparing planning scenarios
- Prioritizing capital improvement projects
- Measuring outcomes/progress over time
- Comparing progress in different places
- Communicating progress




## **Example: Measuring progress over time**





Spending on energy imports, Northwest states



#### Trend at a glance

Energy remains the worst-performing trend in the Cascadia Scorecard. Counting highway fuels and electricity in homes and businesses, Cascadians consume the energy-equivalent of just over two gallons of gasoline per person every day--nearly double the Scorecard model, Germany.

The money the region now pays for fossil fuels would be better spent on conservation, efficiency, and local, renewable energy sources--which would bring economic as well as environmental benefits to the region. A carbon cap-and-trade system, or a carbon tax on fossil fuels (modeled, perhaps, on British Columbia's existing carbon tax), would help reduce the toll of our fossil fuel habit by encouraging a smooth transition to a cleaner and more stable energy system.

Updated June 2010. (Click for more information on Sightline's energy research.)

#### More about energy

What the energy indicator measures and why

#### **Example: Measuring progress over time & comparing regions**

#### HOUSING AFFORDABILITY

Percent of First Time Buyers that Can Afford to Purchase a Median Priced Home 2003-2006



## **Example: Comparing regional plan scenarios**



# HUD DOT EPA PARTNERSHIP FOR SUSTAINABLE COMMUNITIES (PSC)



## **PSC Livability Principles**

- Provide more transportation choices
- Promote equitable, affordable housing
- Enhance economic competitiveness
- Support existing communities
- Coordinate and leverage federal policies and investment
- Value communities and neighborhoods

## **Example performance measurement framework**

## **Principle #1 – Expand Transportation Choices**

Develop more convenient reliable, safe and economical transportation alternatives

Strategies:

Expand highquality transit service to employment centers

Performance measures:

% of all jobs "well served" by transit

% of new homes "well served" by Focus new residential transit development in areas well served by transit

Indicators of progress:

Transit trips per capita

% of commute trips made by transit

VMT per capita

**Broad outcomes:** 

Enhanced accessibility to jobs and services

Lower HH transportation Costs

Improved public health

Improved air quality

Reduced GHG emissions









### Large/Medium Sized Metro Area Performance Measures: Part 1

Pop: Census/ACS;

VMT: MPO or FHWA

Employment: <u>LEHD</u>

cover. NLCD

Performance Measure	Data Source	Tool
Transit trips per capita	Pop: Census/ACS; Transit trips: NTD	Calculator
% of workers commuting by transit,	Census/ACS	<u>FactFinder</u>

bicycle, or foot

capita

by transit

Vehicle miles traveled (VMT) per

% of new homes that are well served

% of new homes within ½ mile of a

% of total employment well served by

% of new construction on previously

Number of affordable homes well

Median household transportation

major employment center

transit (by job location)

developed land

served by transit

costs

New housing units: Local or Census/ACS;

New housing units: Local or Census/ACS

Construction: Local or ParcelPoint; Land

Various variables relevant to calculating

median transport costs: Census/ACS

Transit: Local or TOD Database

Transit: Local or TOD Database

Affordable Homes: Census/ACS

Transit: Local or TOD Database

Employment centers: LEHD

Calculator

**GIS** 

GIS

**GIS** 

GIS / TOD

Database

GIS / TOD

Database

Calculator

11

## **Large/Medium Sized Metro Area Performance Measures: Part 2**

Performance Measure	Data Source	Tool
% of low income households within 30 minute transit commute of major employment center	Low Income Pop: <u>Census/ACS</u> ; Transit: Local or <u>TOD Database</u> ; Employment centers: <u>LEHD</u>	GIS
Acres of agricultural/natural resource land lost per new resident or employee	Pop: <u>Census/ACS</u> ; Employment: <u>LEHD</u> ; Land cover. <u>NLCD</u>	GIS
% of public sector investment in areas well served by transit	Pub. sector inv.: Local Transit. Local or TOD Database	GIS
Dollars of private sector investment in areas well served by transit	Construction: Local or ParcelPoint; Value: Assessment or MLS; Transit: Local or TOD Database	GIS
Annual motor vehicle emissions per capita	Pop: Census/ACS; VMT: MPO or FHWA; Vehicle Fleet profile: Local, State, or NMIM; or Emissions: NEI	Calculator
Bicyclist and pedestrian fatality rate	<u>NHTSA</u>	Calculator
% of homes within ½ miles of recreational opportunities AND neighborhood retail/services	Homes: Census/ACS Parks: Local or NAVTEQ Employment: LEHD	GIS
		12

### **Rural Area Performance Measures: Part 1**

New housing units: Local or Census/ACS

Construction: Local or ParcelPoint; Land cover.

Various variables relevant to calculating median

Employment centers: LEHD

Affordable Homes: Census/ACS

transport costs: Census/ACS

Employment centers: LEHD

Low Income Pop: Census/ACS

Employment: LEHD

**NLCD** 

Note: "Rural Town Centers" must be defined locally. They may be historic main streets or "activity centers" with concentrations of

**GIS** 

GIS

**GIS** 

**GIS** 

OnTheMap

Calculator

13

Performance Measure	Data Source	1001
Transit trips per capita (where applicable)	Pop: Census/ACS; Transit trips: NTD	Calculator
% of workers commuting by transit, bicycle, or foot	Census/ACS	<u>FactFinder</u>
Vehicle miles traveled (VMT) per capita	Pop: Census/ACS; VMT: FHWA (select areas only)	Calculator
% of new homes within ½ mile of rural town centers	New housing units: Local or Census/ACS	GIS

% of new homes within ½ mile of a major

% of new construction on previously

% of total employment within ½ mile of rural

Number of affordable homes within ½ mile

Median household transportation costs

% of low income households within 30

minute commute of major employment

employment center

town centers

developed land

center

of rural town centers

retail/service employment.

#### **Rural Area Performance Measures: Part 2**

Performance Measure	Data Source	Tool
Acres of agricultural/natural resource land lost per new resident or employee	Pop: <u>Census/ACS</u> ; Employment: <u>LEHD</u> ; Land cover. <u>NLCD</u>	GIS
% of public sector investment within ½ mile of rural town centers	Pub. sector inv.: Local	GIS
Annual motor vehicle emissions per capita	Pop: Census/ACS; VMT: MPO or FHWA; Vehicle Fleet profile: Local, State, or NMIM doc; or Emissions: NEI	Calculator
Bicyclist and pedestrian fatality rate	<u>NHTSA</u>	Calculator
% of homes within ½ miles of recreational opportunities AND neighborhood retail/services	Homes: Census/ACS Parks: Local or NAVTEQ Employment: LEHD	GIS
% of new or improved roadways (by mile) that include sidewalks and/or bicycle infrastructure	New roadway miles: Local; New bike/ped. Infrastructure miles: Local	GIS or Calculator
%of non-urbanized area pop. covered by demand response transit service at least 3 days per week	Transit service area: Local; Population: Census/ACS	GIS
Ave. number of daily scheduled intercity bus and rail departures from a rural town center to cities where health care, schools, job centers, and other regional services are available	Transit schedules: Local	Calculator
Economic diversity measures: % of all jobs at the region's three largest employers; % of all jobs in small/medium sized firms; % of jobs in locally controlled firms	Total employment: <u>LEHD</u> ; Employment by firm: Local or <u>Claritas</u>	Calculator

Note: Rural Town Centers must be defined locally. They may be historic main streets or "activity centers" with concentrations of retail/service employment.

# Free Online Tools for Performance Measurement

- Transit Oriented Development (TOD) Database
- Census LED OnTheMap



Performance Measure:

# Percentage of total regional employment near fixed guideway transit

Tool:

**TOD Database** 



### **TOD** Database







Transit Zone: C .25 mile C .5 mile Smart Zoom

🛅 Selected Station 🜘 Station 🔎 Existing Transit 🌘 Potential Transit 📕 Transit Region







## **Step 1: Select data variable of interest**

## **Database**





🙎 Log Out 🛛 😱 User Guide



isting Transit

■ □ GCRTA

eport

eveland Transit R

32 Total Jobs: (1) 03 Total Jobs: (2)

04 Total Jobs: (3)

06 Total Jobs: <sup>(5)</sup>

Reports

**Custom Report** 



Select a report below or build a custom report.

Auto and Non-Auto Commute to Work by Industry Densities

Employment (2002 - 2008)

Household Age

Household Income

Household Type by Income

Housing + Transportation Affordability Index

Vahicles per Workers for Households Under Poverty Status

Journey to Work

Journey to Work by Public Transportation

Mode Share for Persons with Disability

Population and Employment

Race

Tenure

Vehicle Ownership 05 Total Jobs: <sup>(4)</sup>

## Step 2: Select geographic areas of interest

## **TOD** Database

Jabs: (1) | Jobs: (2)


Jobs: (3) 1 1 - 1 - 1 (25)













## Step 3: Click report, Download Excel file

Cleveland Transit Region:	
2002 Total Jobs: (1)	1,060,879
2003 Total Jobs: <sup>(2)</sup>	1,068,588
2004 Total Jobs: <sup>(3)</sup>	1,060,538
2005 Total Jobs: <sup>(4)</sup>	1,065,353
2006 Total Jobs: <sup>(5)</sup>	1,070,079
2007 Total Jobs: <sup>(6)</sup>	1,071,478
2008 Total Jobs: <sup>(7)</sup>	1,039,769
2002 Jobs per Acre: <sup>(8)</sup>	0.61
2003 Jobs per Acre: <sup>(9)</sup>	0.62
2 <mark>004 Jobs per Acre: <sup>(10)</sup></mark>	0.61
2005 Jobs per Acre: (11)	0.62
2006 Jobs per Acre: (12)	0.62
2007 Jobs per Acre: (13)	0.62
2008 Jobs per Acre: <sup>(14)</sup>	0.60
GCRTA .5 Mile Transit Shed: GCRTA 5 Lines; 81 Stations	5
2002 Total Jobs: <sup>(1)</sup>	199,582
2003 Total Jobs: <sup>(2)</sup>	210,133
2004 Total Jobs: <sup>(3)</sup>	199,188
2005 Total Jobs: <sup>(4)</sup>	201,295
2006 Total Jobs: <sup>(5)</sup>	200,120
2007 Total Jobs: <sup>©)</sup>	204,711
2008 Total Jobs: <sup>(7)</sup>	180,458
2002 Jobs per Acre: <sup>(8)</sup>	11.52
2003 Jobs per Acre: <sup>(9)</sup>	12.13
2004 Jobs per Acre: <sup>(10)</sup>	11.50
2005 Jobs per Acre: <sup>(11)</sup>	11.62
2006 Jobs per Acre: <sup>(12)</sup>	11.55
2007 Jobs per Acre: <sup>(13)</sup>	11.82
2008 Jobs per Acre: (14)	10.42



#### Step 4: Calculate % of employment within transit shed, by year



## Other uses of TOD Database

- Measure population near transit
- Measure housing affordability near transit
- Download detailed statistics for individual station areas
- Evaluate station areas for TOD suitability or evaluate performance in TOD station areas
  - See <u>Performance-Based TOD Typology Guidebook</u>
  - See also case studies in <u>TOD Database User Guide</u>





Performance Measure:


## **Distance Traveled to Work**

Tool:


On The Map

### OnTheMap


LED Home Help




## **Step 1: Select geography of interest**



## Step 2: Choose analysis type




## **Descriptions of Analysis Types Available**



วร

### **Step 3: Wait for results**



Privacy Policy | 2010 Census | Data Tools | Information Quality | Product Catalog | Contact Us | Home Source: U.S.Census Bureau, Center for Economic Studies | e-mail: CES.OnTheMap.Feedback@census.gov

### **Step 4: Generate "detailed report"**

#### Detailed Report View

🔑 Export to PDF 💹 Export to XLS 🏽 🔊 Ex


Export to HTML

### Distance/Direction Report - Work Census Block to Home Census Block

Job Counts in Home Blocks by Distance Only																
	20	09	20	08	20	07	20	06	20	05	20	04	20	03	20	02
	Count	Share														
Total Primary Jobs	21,597	100.0%	22,720	100.0%	21,690	100.0%	21,872	100.0%	21,558	100.0%	21,185	100.0%	20,844	100.0%	20,658	100.0%
Less than 10 miles	12,400	57.4%	14,208	62.5%	13,955	64.3%	13,732	62.8%	13,887	64.4%	13,823	65.2%	13,805	66.2%	13,403	64.9%
10 to 24 miles	2,389	11.1%	2,881	12.7%	2,767	12.8%	2,543	11.6%	2,542	11.8%	2,395	11.3%	2,400	11.5%	2,345	11.4%
25 to 50 miles	3,406	15.8%	2,509	11.0%	2,403	11.1%	3,604	16.5%	3,261	15.1%	3,182	15.0%	2,786	13.4%	3,182	15.4%
Greater than 50 miles	3,402	15.8%	3,122	13.7%	2,565	11.8%	1,993	9.1%	1,868	8.7%	1,785	8.4%	1,853	8.9%	1,728	8.4%

Close

#### Distance Traveled to Work, 2002 – 2009 Walla Walla, WA



# Free Online Tools for Mapping Baseline Conditions

- Brookings: <u>Metropolitan Transit Access</u>
- Housing + Transportation Index
- Walkscore
- USDA Food Desert Locator
- ChangeMatters (LandSat imagery viewer)
- NYT: Mapping America (American Community Survey data viewer)



**Benefits**: - Relatively easy to use and interpret

- Great way to visually analyze current conditions in specific locations

**Drawbacks**: - Most provide only one snapshot in time

- Data cannot be downloaded for further analysis

# **Technical Assistance Opportunity**

- EPA's Office of Sustainable Communities is seeking to "pilot test" performance measures in 4 communities
- Selected communities will receive technical assistance during summer/fall 2011
- Selected communities are expected to invest staff time to support performance measurement activity during this period
- EPA seeks volunteer communities in the following categories:
  - Large regional agencies or cities (population > 300,000)
  - Small/Medium-sized regional agencies (100,000 300,000)

- Large suburban municipalities (population 100,000 to 500,000)
- County or regional agency covering a rural areas (with towns less than 50,000)



# How to Express Interest in Technical Assistance Opportunity

- Send a letter of interest to <u>Ramsey.Kevin@epa.gov</u> that includes the following information:
  - Name of MPO/municipality/county seeking assistance
  - Name and contact information for lead staff person who will devote time to supporting performance measurement analysis
  - A brief description of the kinds of issues that your community is most interested in exploring through performance measurement as well as the challenges you have faced in your efforts to do so (data availability, technical capacity, etc.).



# Other Performance Measurement Resources

- http://www.SustainableCommunities.gov
  - Includes <u>resource page on performance measurement</u> that will be updated with new resources as they become available
- EPA: Guide to Sustainable Transportation Performance Measures (to be released very soon)
- Smart Mobility 2010: A Call to Action for the New Decade
- FTA: Transit Performance Measurement
- FHWA: Highway Performance Measurement
- CTOD: Performance-Based Transit-Oriented Development Typology Guidebook
- Bureau of Transportation Statistics Livability Program



## **Questions or Comments are Welcome!**

#### Contact info:

Kevin Ramsey, Ph.D.
Policy Research Fellow
EPA Office of Sustainable Communities

Ramsey.Kevin@epa.gov

202.566.1153



The following slides will not be covered in the 5/26 webinar.

# Additional Resources: Performance Measure Examples



## Principle #2 – Promote Equitable Affordable Housing

Expand access to location and energy efficient housing choices for people of all ages, incomes, races, and ethnicities

#### Strategies:

Implement policy
to promote
housing
affordability near
transit and
employment
centers

Focus new residential development in areas well served by transit and near employment

centers

Performance measures:

# of affordable homes/rentals "well served" by transit

# of affordable homes/rentals near emp. centers

% of new homes "well served" by transit

% of new homes built near emp. centers

Indicators of progress:

% of low income households "well served" by transit

% of low income HH w/in 30min commute of employment centers

#### **Broad outcomes:**

Reduced residential segregation by income

Lower combined cost of housing & transportation

Improved public health

Reduced oil dependence

Improved air quality

Reduced GHG emissions

#### **Performance Measure Example**

(Source: ICF International, fgallivan@icfi.com)

#### Transit Accessible Homes and Jobs

#### **Example Metrics:**

- Percent of population and employment within 0.5 miles of high capacity transit.
- Number of households within 30-minute transit ride of major employment center.

**Metric Variations:** Calculate metrics for low-income populations versus other populations.

#### Data Sources:


Data Point	Data Source				
Location of Rail Stations	National TOD Database				
Transit Level of Service	Google Transit Feed Service (limited data)				
Housing and Population Counts	U.S. Census; American Community Survey				
Job Counts	Longitudinal Employer- Household Dynamics				

#### Measurement Challenges:

- · Level of service information is not consistently available.
- No single national source for data on bus routes. Forecasting locations for new bus stops is challenging.
- Estimating transit travel times requires a travel demand model with a robust transit network.

#### Policies to Improve Performance:

- · Transit system expansion and improvements in level of service.
- Land use policies that cluster development around transit stations and stops.




#### **Examples From MPO Decision Making:**

San Diego Association of Governments: Accessibility Measures

	Long Range Transportation Plan Scenarios							
Goals and Performance Measures	Current (2006)	Revenue Constrained (2030)	Reasonably Expected (2030)	Smart Growth RE (2030)	No Build (2030			
Percent of work and higher education trips accessible in 30 minutes in peak periods	61%	54%	56%	57%	53%			
Percent of work and higher educa	tion trips acces	ssible in 30 minute	s in peak periods	by mode				
Auto	65%	57%	5896	60%	55%			
Transit	10%	13%	1596	16%	10%			
Carpool	67%	64%	6896	70%	59%			
Percent of non-work-related trips accessible in 15 minutes	66%	63%	63%	64%	62%			
Percent of non-work-related trip	s accessible in	15 minutes by m	ode					
Auto	67%	63%	6396	64%	63%			
Transit	4%	6%	7%	7%	4%			
Carpool	68%	66%	6696	67%	64%			

Source: 2030 San Diego Regional Transportation Plan



### **Performance Measure Example**

(Source: ICF International, fgallivan@icfi.com)

# Preserving Open

### Space Example Metrics:

- Percent of new housing units built on previously developed land.
- Percent of new commercial floorspace built on previously developed land.

### Metric Variations:

- Constrained lands consumed for new transportation infrastructure.
- Number of residential units and square feet of non-residential space near agricultural and natural resource lands.
- Acres of farmland converted to urban uses.

### Data Sources:

Data Point	Data Source
Current/Previous Land Use	National Land Cover Database
Location of New	Tax Assessor Data; Building
Development	Permit Data



### **Measurement Challenges:**

- In long range transportation planning, land use forecasts generally do not vary between alternatives.
- No single source for spatial data on new construction.

### Policies to Improve Performance:

- Establish urban growth boundaries.
- Require concurrency between land development and infrastructure availability.
- Require maintenance of existing infrastructure before construction of new infrastructure.
- · Community-based long-term land use visioning processes.

### **Examples From MPO Decision Making:**

Puget Sound Regional Council:

Development on Parcels in Proximity to Resource and Agricultural Lands (Change from 2040 Baseline)

5.096
4.096
3.096
1.096
-2.096
-1.096
-2.096
-3.096
-5.096
-5.096
Alt 1 Ak 2 Alt 3 Alt 4 Ak 5

Source: PSRC Transportation 2040

Mid-Ohio Regional Planning Commission: Comparison of Transportation and Land Use Alternatives


Scenarios	VMT vs. Current	Total Sq. Miles	% New on Greenfields	
		Developed	Housing	Jobs
Trend	45%	1,543	84%	91%
Shifting Inward	40%	1,440	84%	91%
Shifting Inward with Increased Transit	31%	1,370	73%	61%
Aggressively Inward	21%	1,186	51%	22%

Source: MORPC Regional Fact Book (August 2004)

### **Performance Measure Example**

(Source: ICF International, fgallivan@icfi.com)

# Promoting Alternative Modes Over Single Occupancy Vehicles



### **Example Metrics:**

- Bicycle, pedestrian, and transit mode share.
- VMT per capita.
- Average Vehicle Occupancy.

#### Metric Variations:

Bicycle and pedestrian level of service.

### **Data Sources:**

Data Point	Data Source
Commute Trips— Mode and Length	U.S. Census; American Community Survey
All Trips—Mode and Length	Local Travel Surveys
System-Level Transit Ridership	National Transit Database
Vehicle Miles Traveled	Highway Statistics (appropriate for some isolated urban areas); Travel Demand Models


### Measurement Challenges:


- Highway Statistics data on VMT includes pass-through VMT from surrounding communities.
- Most travel models have limited ability to represent trips by alternative modes.
- · Most travel models have limited ability to capture the impact of small-scale land use changes or improvements to bicycle and pedestrian facilities.


### Policies to Improve Performance:

- Improvements to bicycle and pedestrian environments and transit systems.
- Employer-based or residence-based transportation demand management programs.
- Transportation pricing.
- · Land use changes that improve access to alternative modes.

### **Examples from MPO Decision Making:**








### **Performance Measure Example**

(Source: ICF International, fgallivan@icfi.com)

## Household Transportation Costs

### **Example Metrics:**



### Metric Variations:

- Include non-commute trips.
- To represent affordability, calculate transportation costs relative to income.
- · To capture the tradeoff between housing and transportation expenditures, include housing costs.

### **Datas Sources:**

Data Point	Data Source	
Commute Trips—Mode and Length	U.S. Census; American Community Survey	
All Trips—Mode and Length	Local Travel Surveys	
Cost Factors	Transportation Energy Databook; National Transit Database	




### **Measurement Challenges:**

- Little empirical data on non-work trips available by city or region. Must typically be modeled.
- · Little to no data available on parking costs.
- · For affordability, must have data on household incomes.
- Difficult or impossible to forecast changes in housing costs.

### Policies to Improve Performance:

- Provide and promote lower cost modes of transportation.
- · Promote housing closer to jobs for all income levels.

### **Example From MPO Decision Making:**



# Metric: % of new homes built near transit (or activity center)

**Detailed** description

Percentage of all new homes built that are located within ½ mile of a "well served" transit stop (or "major activity center" in regions without regular transit service)

**Appropriate** 

Regional (ideal)

scale(s) of

Municipal

measurement Key

 Well served transit stop/station (FTA) Major activity center

definitions **Transit (2 options)** Data **Elements** 

 Location of "well served" transit stops (local) • Fixed guideway transit stop locations (TOD Database)

**Home construction (2 options)** Home construction or permit data (local)

Housing units by block group (Census/ACS)

# Metric: Number of affordable homes near transit (or activity center)

Detailed description

Number of housing units or rental units with cost/rent less than 30% of area median income (AMI) within ½ mile radius of a well served transit stop (or "major activity center" in regions without regular transit service)

Appropriate scale(s) of measurement

Key

Data

**Elements** 

RegionalMunicipal

• Mullicipa

definitions

Affordable home

Major activity center

Transit (see prior slide)

- Affordable homes: (all data from Census/ACS)
- Homeowner-occupied housing costs

Well served transit stop/station (FTA)

Renter-occupied housing costs

# Metric: Percentage of workers commuting by transit

Detailed

Percentage of all workers in an area who use transit description as their primary mode of transportation to work

Tools needed

for analysis

Regional

scale(s) of Municipal Census Tract

**Data Elements** % of workers commuting by transit (Census/ACS)

Census American Fact Finder

measurement

**Appropriate** 

INIETRIC: I	ransit trips per capita
Detailed	The total daily number of trans

The total daily number of transit trips per resident. description

Regional

Municipal

Data **Elements** 

**Appropriate** 

measurement

scale(s) of

Number of annual unlinked transit trips for each transit agency

Source: <a href="http://www.ntdprogram.gov/ntdprogram/">http://www.ntdprogram.gov/ntdprogram/</a> Resident population (by metro area or city)

 Source: Decennial Census or American Community Survey

Tools needed

for analysis

Census American Fact Finder

Spreadsheet or calculator

43

# Metric: Percentage of workers commuting by bicycle

**Detailed** Percentage of all workers in an area who use transit description (or bicycle) as their primary mode of transportation

to work

Census American Fact Finder

% of workers commuting by transit (Census/ACS)

Regional

Municipal

None

Census Tract / TAZ

**Appropriate** 

measurement

**Key definitions** 

**Data Elements** 

Tools needed

for analysis

scale(s) of

# **Additional Resources: Common Data Sources**



# American Community Survey (ACS) 5-Year Estimate

- New Census product
- Updated yearly, starting in 2010
- Data available for all census block groups in the U.S.
- Summary file retrieval tool available at:
  - http://www.census.gov/acs/www/data\_documentation/summary\_file/




# **Census Summary File Retrieval Tool**

Macro for use in Microsoft Excel 2007 or higher

Step 1 of 2: Select a major geographic area and dataset

http://www.census.gov/acs/www/data\_documentation/summary\_file/

X



# Some ACS Variables of Interest

## Transportation

- Means of transportation to work
- Housing affordability
- Selected monthly owner costs
- Gross rent
- Median household income

Housing unit counts (e.g., for estimates of new construction)

Housing units



# **Some Transit Data Sources**


- Passenger counts by transit agency
  - National Transit Database
- Fixed-guideway transit stop locations
  - <u>TOD Database</u> (station data available for download upon request)
- Local area bus transit stops and service
  - Data only available locally. Many agencies are <u>sharing data in GTFS</u> format. <u>GTFS data can be converted</u> for analysis in GIS.



# Tools for Mapping Baseline Conditions




Browse local data from the Census Bureau's American Community Survey, based on samples from 2005 to 2009. Because these figures are based on samples, they are subject to a margin of error, particularly in places with a low population, and are best regarded as estimates.



### Metropolitan Transit Access: Job access

Share of jobs reachable in a set time



### Average Jobs reached in 90 minutes (share of all metro jobs)

Total: 391,860 (59% metro)

From low-income: 461,621 (69% metro)
From middle-income: 394,778 (59% metro)
From high-income: 314,763 (47% metro)

## http://htaindex.cnt.org/

Region: Fresno, CA Region

Typical Household: Regional Median Income: \$34,960 Size: 2.5 People Commuters: 1.2 Workers

### Transit Ridership, % of Workers Change

Data Not Available

Less than 1%

1 to 4% 4 to 8%

8 to 14%

14% and Greater

Transit Ridership represents the percentage of workers in a Block Group who utilize Public Transportation (Transit) as their primary mode of transportation to work.

### Transit Access Index (TAI)

Data Not Available

Less than 1 Opportunties
1 to 3 Opportunties


3 to 9 Opportunties

9 to 27 Opportunties

27 Opportunties and Greater


The Transit Access Index (TAI) was developed by CNT as a measure of transit availability. The TAI is based on the number of bus routes and train stations within walking distance for households in a given Block Group. The TAI does not include the Frequency of Service. This measure is not available to all metro areas because of data acquisition issues.





▼ Change

## Some variables available through H+T Index website.



Income Thange

aloped as a more complete bility beyond the standard r Housing Costs, By taking in s a more complete underst ding these costs by Repres

hald by H+T aynanege Wh






Cities & Neighborhoods | Why It Matters | How It Works | Add Walk Score to Your Site | Blog

### Type an Address:

Go

ghborhood	Score
Midtown	85
Montrose	84
Downtown	82
River Oaks	77
Rice	73
Galleria-Uptown	70
Rice Military	70
Westchase	65
Greater Heights	64
West Houston	59
Medical	58
Bellaire	56
East End	55
Spring Branch	54
North	51
Meyerland	50
Sugarland	49
Southeast	47
Northwest	47
Pasadina	42
Northeast	40
Southwest	35
Far Northeast	30
	Midtown Montrose Downtown River Oaks Rice Galleria-Uptown Rice Military Westchase Greater Heights West Houston Medical Bellaire East End Spring Branch North Meyerland Sugarland Southeast Northwest Pasadina Northeast Southwest



Moving To Order your Buy | Move

Find Senio Free assist

www.relocat

www.aplace

Houston, Homes, Pro

in Houston www.zuccar

3 Credit S

Absolutely Yours Now

FreeScore.co




Housto

Check the

Choose a k

Chear



# ChangeMatters - Infrared

http://www.esri.com/landsat-imagery/

